### Roland

Copyright © 2007 ROLAND CORPORATION
All rights reserved. No part of this publication may be reproduced in any form without the written permission of ROLAND CORPORATION.


#### **SA-1000** Connection Guide

When connecting the SA-1000 with other equipment, be sure to read the owner's manuals for the SA-1000 and each device being connected.

## Turn Off the Power to All Devices

Turn down the VOLUME knobs on all devices being connected to lower the volume completely, then turn off their power.

#### SA-1000's Control Panel



Turn all VOLUME knobs to MIN

Turn off the power



Also lower the VOLUME on the keyboard you're connecting to the minimum level, then turn off the power. Be sure to refer to the owner's manual for the keyboard you're connecting before carrying out this procedure.


Keyboard to be connected




## **2** Connect the Keyboard

Use a connecting cable (optional) with 1/4" phone plugs to connect the keyboard's output jacks to the SA-1000's KEYBOARD IN jacks.

To KEYBOARD IN jacks on rear panel




#### Connect the Subwoofer (SA-1000W)




# Turn on the Power

Turn on the power to the devices in the sequence described below. Switch on the power according to the instructions in the owner's manuals for the SA-1000 and each device being connected.








## 4 Adjust the Volume


First, raise the keyboard's volume, then increase the SA-1000's INPUT VOLUME settings.



Raise the keyboard's volume to 60–70% of the maximum level. However, if speakers are connected, set the volume to a listenable level.



If using Stereo Link, the settings for the MASTER section of both SA-1000s need to be set so they match.



Raise the volume to 60%–70% of the maximum level.

Adjust the overall volume level with the MASTER VOLUME knob.

